



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

DEMAND REGISTERS

Oil residues, gum sediments and grease are easily removed from demand registers adding years of life and accuracy. Non-abrasive, cleaning with L&R Ultrasonic Cleaning Systems saves hours of hand cleaning. Simply-

1. Place in basket and immerse in main tank containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Heavy Duty Solvent Free Degreaser Concentrate at the recommended dilution rates (see product label).
2. Cavitate 3-7 minutes.
3. Rinse well under warm running water.
4. Air dry or dry using warm air (forced air dryer).

EQUIPMENT NEEDED:

Machines, Accessories*: 2014, Q140 or S140 Ultrasonic Cleaning System with Timer, Optional Heater**, Auxiliary Pans, Basket.

Solution: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (Product Code 110); SF-50 Heavy Duty Solvent Free Degreaser Concentrate (Product Code 071).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning. Please contact an L&R Sales Specialist to determine your cleaning needs.

**Heater not available on 2014.