



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

LAPIDARY, GEMS, ROCKS, MINERALS

Gems, rocks, antiques, minerals, fossils, and jewelry all have one thing in common they must be clean to be appreciated. Non-abrasive cleaning is the answer with an L&R Ultrasonic Cleaning System. Simply-

1. Place Basket of specimens into tank containing proper dilution of Ellanar Jewelry Cleaner Concentrate (1 part cleaner: 7 parts water).
2. Cavitate 5-10 minutes.
3. Remove, rinse thoroughly with water and dry.
4. Notes:
 1. Keep tank bottom free of silt, sediment and heavy specimens.
 2. Acidic solutions must be used in Pyrex Beakers. Do not put acid solutions directly in tank.

EQUIPMENT NEEDED:

Machines, Accessories*: 2014, Q90 - Q280, S140 – S280 or appropriate sized Ultrasonic Cleaning System to match volume and size of specimens: Basket, Positioning Cover, Beakers, Auxiliary Pans, Optional Heater.

Solution: Ellanar Jewelry Cleaner Concentrate (Product Code 170).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.