



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

LENSES

(after grinding and buffing)

After grinding and buffing lenses, but before heat treating for break resistance, insure yourself against any foreign residue being burned into the lenses. L&R Ultrasonic Cleaning Systems offer the most complete cleaning possible. Simply-

1. Fill tank 1/2 to 3/4 full with Optical Cleaning Solution.
2. Place lenses in lens holder and immerse in solution. Cavitate for 2-3 minutes.
3. Remove, rinse thoroughly in water.
4. Dry thoroughly.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90 Ultrasonic Cleaning System with Timer, Optional Heater, Auxiliary Pan, Basket.

Solutions: Optical Cleaning Solution Concentrate
(Product Code 216).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

APPLICATION BULLETIN #23