



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.Lrultrasonics.com

MOBILE COMMUNICATION SETS

3-Way radios, handsets, walkie-talkie sets, etc. need no longer be sent to the manufacturer for rehabilitation. Dirt, dust, rust, and oxidation can be removed quickly, safely, and thoroughly with an L&R Ultrasonic Cleaning System. Simply-

1. Remove housing before cleaning.
2. Place entire set into Basket and put into tank #1 containing #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution.
3. Cavitate 4 minutes. Lift out and let drain (60 seconds).
4. Immerse Basket into tank #2 containing L&R Instrument Rinsing Solution.
5. Cavitate 4 minutes. Lift out and drain. Air dry.
6. Test and reinstall.

EQUIPMENT NEEDED:

Machines, Accessories*: Q210, Q280, S200 or S280 Ultrasonic Cleaning Systems, Timer, Auxiliary Pan, Basket.

Solutions: #222 Non-Ammoniated Ultrasonic Cleaning Solution (Product Code 191); Instrument Rinsing Solution (Product Code 194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.