



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

PILL MARKING DIES

Archaic hand-scrubbing methods lose out to Ultrasonic Cleaning Systems by L&R. Fast, thorough, and economical cleaning the easy way. Simply-

1. Place rack of dies into tank containing properly diluted Aqualar #1 Cleaning Solution Concentrate or SF-50 Heavy Duty Solvent-Free Degreaser Concentrate (diluted per container directions).
2. Cavitate for 12 minutes.
3. Remove, rinse thoroughly with water.

EQUIPMENT NEEDED:

Machines, Accessories*: Q650 or S650 Ultrasonic Cleaning System with Timer, with Optional Heater, Basket or Rack.

Solution: Aqualar #1 Cleaning Solution Concentrate (Product Code 203); SF-50 Heavy Duty Solvent-Free Degreaser Conc. (Product Code 071).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

APPLICATION BULLETIN #31