



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

EYEGASSES, CONTACT LENSES

Fingerprints, smoke film, perspiration and miscellaneous debris frequently resist hot water, detergents and time consuming hand cleaning. Thorough and fast cleaning is yours with L&R Ultrasonic Cleaning Systems. Simply-

1. Fill tank 1/2 to 3/4 full of Optical Cleaning Solution Concentrate diluted per label instructions.
2. Place folded eyeglasses in Basket of main tank (lenses up).
3. Place hard contact lenses into any standard lens holder. Fill holder with clean solution and clean in main tank. (Make certain solution completely covers lenses.)
4. Cavitate for 2-3 minutes.
5. Remove, rinse thoroughly in water, dry.

Note: Check jeweled or decorated frames for loose stones.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90 Ultrasonic Cleaning System with Timer, Optional Heater, Auxiliary Pan, Basket.

Solutions: Optical Cleaning Solution, Concentrate (Product Code 216).

CAUTION: Use same procedure for soft contact lenses. However, only saline solution or other solutions recommended by lens manufacturer should be used for cleaning and rinsing.

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.